Large Decal Application Instructions

WET INSTALL

Best for: Very large decals, complex alignment, precise positioning, bubble free application.

You will need:
- **Spray bottle**
- **Application Fluid (or water + 2–3 drops of dish soap (DO NOT over-soap)**

***You can find full mixtures online.**
- **Application Squeegee (Felt edge recommended)**
- ***Isopropyl alcohol**
- **Clean cloth**

Steps:

1. Clean the surface with application fluid or isopropyl alcohol and allow it to dry.

2. With the decal face down, slowly and carefully remove the backing paper (repress with squeegee if decal remains attached to backing paper).

4. Lightly mist the receiving surface and the adhesive side of the decal. (Decal and surface are misted to avoid sticking and allow positioning - do not completely soak the decal)

5. Carefully position the decal on the surface — it will be adjustable while wet.

6. Once the decal is in position squeegee from the center outward, removing all liquid and air bubbles.

7. Allow the decal to set and dry for atleast 10–15 minutes (may take longer)

8. Squegee decal once more.

9. Remove the transfer tape slowly and carefully at a sharp angle. (If the decal starts to lift lay it back down then firmly repress and repeat.)

10. Re-squeegee with felt edge or press down with fingers if needed. (Be careful not to cause scratches)

Important Notes:
- **Allow 24–48 hours for full adhesion**
- **Do not wash or expose to heavy moisture during this time**
- **Small bubbles may disappear as moisture evaporates**

Large Decal Application Instructions

DRY INSTALL (Recommended for Most Installations)

Best for: Flat or lightly curved surfaces, indoor installs, and long-term durability.

You will need:
- **Masking tape**
- **Squeegee (felt edge preferred)**
- **Decal Application Spray or Isopropyl alcohol (70%+)**
- **Clean lint-free cloth**

Steps:

1. Clean the surface thoroughly using Decal Application spray or isopropyl alcohol. Surface must be clean, dry, and free of wax, dust, or oils.

2. Position the decal on the surface using masking tape to hold it in place. Measure and level before proceeding.

3. Create a hinge in the center of the decal by taping halfway across the top or side (depending on the height/width).

4. Peel the backing paper away from the vinyl slowly, exposing the adhesive.

5. Once you've peeled to the hinge, carefully trim the peeled backing paper. (We suggest having someone hold the exposed decal upright while another person trims the backing paper away.)

6. Start carefully applying the decal from the center out. (Leave a small gap between your hinge and where you start applying so you can freely lift the hinge and peel backing paper from the other side.)

7. Use firm overlapping strokes with the squeegee to avoid bubbles.

8. Once the first half is pressed down and applied, carefully remove the backing paper from the other half of the decal and repeat the process applying from the center hinge out. (Make sure to get all air bubbles out at this stage and that the entire decal has been pressed down firmly.

9. Remove the remaining transfer tape slowly at a sharp angle (180° back over itself).

10. Post-squeegee any areas that may need extra pressure (use felt tip squeegee or finger to avoid scratches.

Important Notes:
- **Do not apply below 50°F or above 90°F**
- **Avoid washing or exposing to moisture for 24 hours**